

Retain this information, addresses and phone numbers for future reference. Content may vary from pictures.

BATTERY SAFETY INFORMATION: Batteries are small objects. Replacement of batteries must be done by adults. Follow the polarity (+/-) diagram in the battery compartment. Promptly remove dead batteries from the toy. Dispose of used batteries properly. Remove batteries for prolonged storage. Only batteries of the same or equivalent type as recommended are to be used. DO NOT incinerate used batteries. DO NOT dispose of batteries in fire, as batteries may explode or leak. DO NOT mix old and new batteries or types of batteries (i.e. alkaline/standard/rechargeable). Using rechargeable batteries is not recommended due to possible reduced performance. Rechargeable batteries are only to be charged under adult supervision. Rechargeable batteries are to be removed from the toy before being charged (excluding LiPo batteries). DO NOT recharge non-rechargeable batteries. DO NOT short-circuit the supply terminals.



How To Train Your Dragon: The Hidden World © 2019 DreamWorks Animation LLC.
All rights reserved. / Tous droits réservés.
www.dreamworksanimation.com

T66631-0001-20106070-GEN-15-R2-Hatching Dragon



Spin Master logo & © Spin Master Ltd. Patent pending. All rights reserved.

SPIN MASTER LTD., 225 KING STREET WEST, TORONTO, ON M5V 3M2 CANADA

Imported into EU by/Importé dans l'UE par SPIN MASTER INTERNATIONAL B.V., KINGSFORDWEG 151, 1043 GR AMSTERDAM, THE NETHERLANDS

Imported by / Importé par SPIN MASTER AUSTRALIA PTY LTD, Suite 101, Level 1, 18-24 CHANDOS STREET, ST LEONARDS, NSW 2060; © 1800 316 982

MADE IN CHINA

WWW.SPINMASTER.COM

12

DREAMWORKS
HOW TO TRAIN YOUR
DRAGON
THE HIDDEN WORLD

5+
years

Easy to follow instruction videos:
spinmaster.com/hatchingtoothless

CONTENTS

1
Hatching Dragon (in egg)

1
Hatching Dragon Egg

2
AA (LR6) Batteries

1
Accessory

1
Instruction Guide



⚠️ **WARNING: CHOKING HAZARD** - Small parts. Not suitable for children under three years.
This toy contains accessible magnets. Keep away from electronic and medical devices.



NORTH AMERICA - 1-800-422-8339, customerservice@spinmaster.com
UK - 0800 204 1191, serviceuk@spinmaster.com

IRELAND - 1800 992 349

AUSTRALIA - 1800 316 982, customerservice@spinmaster.com

WWW.SPINMASTER.COM



WWW.SPINMASTER.COM

1

GETTING STARTED

When you first get your egg out of the box, to turn it on, remove the twist locks located at the bottom of the egg. Discard the twist locks.

THINGS YOU NEED TO KNOW

1. I only hatch once.
2. Before I hatch, you must play with me in my egg.
3. After a period of inactivity, egg will go to sleep.
4. If my egg is off, hold the bottom of the egg to wake me up.

CARE AND SAFETY

- The egg is VERY FRAGILE. Always use two hands.
- Accidentally breaking the egg results in missing the hatching experience.
- To clean, wipe me gently with a clean damp cloth.
- Keep the top of the egg away from your eyes and face during the hatch.
- DO NOT submerge me in water. This will damage the electronics.

ACCIDENTALLY BROKE THE EGG?

Be very careful with the egg. If it accidentally breaks before I'm ready to hatch, you cannot put me back in the egg. If you break the egg before I'm ready to hatch, follow steps 3-4 on page 4.

"HATCHING TIME!"

WWW.SPINMASTER.COM

2



Requires 2 x 1.5 V AA (LR6) batteries (included). Batteries or battery packs must be recycled or disposed of properly. When this product has reached the end of its useful life, it should not be disposed of with other household waste. The Waste Electrical and Electronic Equipment Regulations require it to be separately collected so that it can be treated using the best available recovery and recycling techniques. This will minimize the impact on the environment and human health from soil and water contamination by any hazardous substances, decrease the resources required to make new products and avoid using up landfill space. Please do your part by keeping this product out of the municipal waste stream! The "wheeled bin" symbol means that it should be collected as "waste electrical and electronic equipment". You can return an old product to your retailer when you buy a similar new one. For other options, please contact your local council.

FCC STATEMENT: This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this toy does cause interference to radio or television reception (you can check this by turning the toy off and on while listening for the interference), one or more of the following measures may be useful: • Reorient or relocate the receiving antenna • Increase the separation between the toy and the radio or the TV • Consult the dealer or an experienced TV-radio technician for help.

NOTE: Changes, adjustments or modifications to this unit, including but not limited to, replacement of any transmitter component (crystal, semiconductor, etc.) could result in a violation of FCC rules under part 15 and/or 95 and must be expressly approved by Spin Master Ltd. or they could void the user's authority to operate the equipment. Spin Master Inc., P.M.B. #10053, 300 International Drive, Suite 100, Williamsville, NY 14221. To contact the responsible party please visit fcc.spinmaster.com.


WWW.SPINMASTER.COM

11

HOW TO INSTALL BATTERIES

For best results, put in new batteries after your Hatching Dragon hatches.

1. Open the battery door with a screwdriver.
2. If used batteries are present, remove these batteries from the unit. DO NOT remove or install batteries using sharp or metal tools. Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.
3. Replace battery door securely.
4. Check your local laws and regulations for correct recycling and/or battery disposal.



LOW BATTERIES


Eyes will flash and Hatching Dragon will snore when batteries are low.

IN-EGG PLAY!


****When you excite me enough, I am ready to hatch!**** Don't worry, I cannot hatch without your help.



Twist locks located at the bottom of the egg. Discard the twist locks.




Unbox my egg and I will make sounds.




Leave my egg alone and I will fall asleep. To wake me up, hold the bottom of my egg.



Gently shake my egg to make me angry. The longer you shake me the angrier I will get.




Tilt the egg upside down and right side up to play with me.



I can tap on the inside of the egg to communicate with you. Tap on my egg and I'll tap back. I can only hear you when I'm quiet!

HATCHING TIME!

1. Once you hear my egg begin to crack, hold me upright to help me hatch.
2. Keep the top of the egg away from your eyes and face during the hatch.
3. Discard extra eggshell pieces that might block my way.
4. Now pull me out of the egg!



GAMES

2. DRAGON TRAINER

Turn dial to 2. Press belly to start game. For best results when playing, hold the dragon by the sides to avoid hitting the belly sensor. If do an ACTION, and you give the correct COMMAND as fast as you can, make sure to give me the right command or we'll have to start over. How long do you think you can keep up?

ACTION: my head moves side to side -- tap my head sensors.

ACTION: My mouth lights up -- tap my belly sensor.

ACTION: I flap my wings -- lift me into the air.

3. ROAR BACK

Turn dial to 3. Roar at me and I will roar back. Try roaring louder and longer to see if I can keep up!

4. ASK TOOTHLESS

Turn dial to 4. Ask me "Yes" or "No" questions and I will respond to you with an answer. If my eyes light up and wings flap, that means yes! If I plasma blast you, that means no. Sometimes I will tilt my head side to side. If I just don't know, maybe you can ask again later!

5. DRAGON FIRE (multiple player)

Turn dial to 5. Hold my belly to start my plasma charge, pass me around like a "hot potato" while I am charging up to plasma blast. I will randomly plasma blast a player at any time during the game. Try not to get blasted! Hold my belly to start the charge again if you want to play another round.

6. FOLLOW THE ALPHA

Turn dial to 6. Press belly to start game. Can you keep up with me? I will create sequences with my movements, lights and sounds. See how long you can repeat after me.

ACTION: My eyes light up -- tap my head sensors.

ACTION: I plasma blast -- tap my belly sensor.

ACTION: I make a flying/soaring sound -- lift me straight up in the air.

7. DRAGON DANCE

Turn dial to 7. Watch me dance to your favorite tunes. I will rock back and forth when I hear music. You could sing to me too!



MORE WAYS TO PLAY

1. AUTONOMOUS MODE

Turn dial to 1 for autonomous mode, and these are the things we can play.

A. RIDER'S BOND

Place your hand on my head for rider's bond. I will react with eyes dimming and purring.

B. PLASMA BLAST

Hold my belly to charge up my plasma blast, release to blast. My mouth will glow when charging and blasting.

C. DRAGON AND RIDER

Teach me how to fly by picking me up and moving me in an S shape. I will flap my wings and make flying sounds when you do this motion and lift me high into the air.

D. ANNOY ME







Shake me, hold me upside down, or tap on my head to annoy me. I will respond with lights and angry sounds, I may even try to plasma blast you!

E. FEED TOOTHLESS

Feed me with the fish if I get hungry by holding the fish accessory up to my mouth, making contact with the 2 scales.


F. SLEEP

Lay me on my side to put me to sleep, you'll hear me snore as I nap. Try poking my head or belly as I snore. I'll also fall asleep if you leave me alone for too long. If I stop snoring and fall asleep completely, place and hold your hand on my head to wake me up.




WWW.SPINMASTER.COM

Hatching Dragon




TILT SENSOR





Rotate the dial to select a game mode.

- 0. Off
- 1. Autonomous mode
- 2. Dragon Trainer
- 3. Roar Back
- 4. Ask Toothless
- 5. Dragon Fire
- 6. Follow the Alpha
- 7. Dragon Dance

WWW.SPINMASTER.COM



- EGG BASE**
1. Once I'm out of the egg, A. Twist the post clockwise to unlock it, B. Then pull it out.
 2. Put me in my egg base so I can rock and play!
- When I'm sleepy, put me in my egg base for a nap.



- FEED ME**
- Hold fish to my mouth to feed me, with my nose making contact with the 3 scales.
- A. WARNING:** The toy cannot rotate! Rotate right! Keep away from eyes and nose area!

ACCESSORY



Holding my belly will charge up a plasma blast. Go ahead press and hold my belly to give it a try. Hold me like this in order to not accidentally trigger plasma blasts.

HOW TO HOLD YOUR DRAGON